



# **BULLY DOG**

## **POWER WIRE FUSES**

This is the list of recommended fuses to use when installing the power wire provided in the GT installation kit

### **GM**

**1999-2014 GM GAS**

IGN3 (CAB)

**2001-2007 GM DIESEL**

IGN3 (CAB)

**2007.5-2013 GM DIESEL**

FUSE 45 (HOOD)

### **FORD**

**2004.5-2008 F150**

FUSE 18 (CAB)

**2009-2010 F150**

FUSE 16 (CAB)

**11 + F150**

FUSE 28 (CAB)

**1999-2010 DIESEL**

FUSE 27 (CAB)

**2011-2014 DIESEL**

FUSE 28 (CAB)

### **DODGE / JEEP / CHRYSLER**

**2006-2010 DODGE/CHRY CARS**

FUSE 28 (HOOD)

**2006-2013 RAM GAS**

FUSE 28 (HOOD)

**2007-2014 JEEP**

FUSE M27

**2010-2012 6.7 DIESEL**

M45 (HOOD)

**2003-2009 DIESEL**

FUSE 28 (HOOD)

### **TOYOTA**

**2007-2008 TUNDRA**

FUSE 54 (CAB)

**2009 TUNDRA**

FUSE 20 (CAB)

**2009 TACOMA**

FUSE 8 (CAB)

**2008-2012 SEQUOIA**

FUSE 24 (CAB)

**2010-2011 TACOMA**

FUSE 9 (CAB)

**2010-2012 TUNDRA**

FUSE 21 (CAB)

**2010-2012 4RUNNER**

FUSE 15 (CAB)

### **NISSAN / INFINITY**

**2005-2013**

FUSE 27 (HOOD)

Any questions or concerns, please contact Technical Support. 940-783-9915